Muon Lifetime Experiment Summary

Nicholas Lyu^{1,*} and Adam Pearl^{1,†}

¹Harvard University

(Dated: January 25, 2022)

I. EXPERIMENT GOALS

The primary objective of this experiment is to measure the lifetime of a muon (τ_{μ}) by observing its decay and fitting the resulting exponential distribution. This measurement also allows us to infer the Fermi constant (G_F) since $\tau_{\mu}^{-1} \propto G_F^2$. Additionally, we aim to determine the muon rest mass by analyzing the energy spectrum of decay electrons.

- 1. Measure the lifetime of a muon τ_{μ} and extract the weak force coupling constant G_F .
 - (a) Muons originate from cosmic ray interactions, where pions and kaons decay into muons and muon neutrinos.
 - (b) Muons decay via weak interaction:

$$\mu^- \to e^- \bar{\nu}_e \nu_\mu,$$
 $\mu^+ \to e^+ \nu_e \bar{\nu}_\mu.$

(c) Negative muons can also be absorbed in matter:

$$\mu^- p^+ \to n \nu_\mu$$
.

The probability of capture depends on the atomic number Z and scales roughly as Z^4 for low Z. Since we use a plastic (hydrocarbon) scintillator, we approximate it as carbon.

(d) The decay rate follows:

$$-\frac{dN}{dt} = N_0 \Gamma_{\mu} e^{-\Gamma_{\mu} t}.$$

Taking the logarithm, we obtain a linear form:

$$\ln\left(-\frac{dN}{dt}\right) = \ln(N_0\Gamma_\mu) - \Gamma_\mu t.$$

We fit this to extract Γ_{μ} , from which τ_{μ} can be determined.

^{*} nicholaslyu@college.harvard.edu

[†] apearl@college.harvard.edu

- 2. Measure the muon rest mass by analyzing the decay electron energy spectrum.
 - (a) In the decay $\mu^- \to e^- \bar{\nu}_e \nu_\mu$, energy conservation dictates that the electron carries roughly half of the muon's rest energy.
 - (b) The energy spectrum of electrons is analyzed to identify the high-energy cutoff, which provides an estimate of the muon mass.
 - (c) Calibration is performed using the energy deposition (dE/dx) of minimally ionizing muons.

II. EXPERIMENTAL CONSIDERATIONS

- 1. **Trigger Calibration:** The detection system must effectively filter out non-muon events. The muon signature is identified using:
 - Start Signal: $T \wedge M \wedge \overline{B}$, indicating a muon stopping in the middle detector.
 - Stop Signal: Any secondary signal in M, or an event where the electron escapes upward $(T \wedge M \wedge \bar{B})$ or downward $(\bar{T} \wedge M \wedge B)$.

A gate lasting several muon lifetimes is implemented, and the B signal is extended to prevent false triggers.

- 2. Scintillation and Detection: Muons excite the plastic scintillator, producing light that is detected by the photomultiplier tubes (PMTs).
 - The PMT converts light into an electrical signal via the photoelectric effect.
 - The signal is amplified through a cascade of dynodes, creating a measurable output.
 - Possible issues include afterpulsing from ionized residual gases inside the PMT.
- 3. **Data Acquisition and Analysis:** The oscilloscope and LabVIEW software record time intervals between the start and stop signals. A histogram of these delays should follow an exponential decay, allowing τ_{μ} extraction through curve fitting.

III. SAFETY CONSIDERATIONS

1. High Voltages:

- PMTs operate at -2.0 kV to -2.4 kV. Handle cables carefully.
- DO NOT hot-plug high voltage connections.

2. Radiation:

- Cosmic ray muons pose no significant health risk.
- Ensure proper shielding of electrical components.

IV. QUESTIONS

- 1. Why do we only consider muons that stop in the middle detector for lifetime measurements?
- 2. Are we fitting τ_{μ} from the decay rate equation, or are we directly measuring lifetimes from individual events?
- 3. What are the primary sources of background noise in the signal, and how do we mitigate them?
- 4. How does the discriminator threshold affect the efficiency of the detector, and how should it be calibrated?
- 5. How does the afterpulsing effect in PMTs influence our measurements, and what techniques can be used to suppress it?